

Bedienungsanleitung

Spannungsverstärker 5V10

Instruction manual

voltage amplifier 5V10



**Bitte die Bedienungsanleitung vor dem Anschalten des Gerätes sorgfältig lesen.
Beachten Sie bitte insbesondere die Sicherheitshinweise!**

**Read carefully before switching on the power! Please see also see instructions
for safety, using piezoelectric actuators and power supplies!**

Seriennummer / Serial Number: E -





Bedienungsanleitung (deutsch)	Seite	3 ... 11
Instruction manual (english)	page	13 ... 21

Deutsche Version: Letzte Änderung 03.12.2007 von DW
english Version: last change 2007-12-03 by DW



Table of contents (english)

1.	Introduction	14
2.	Certification of piezosystem jena	14
3.	Declaration of conformity	15
4.	Instructions for using piezoelectrical elements and power supplies	16
5.	Safety Instruction.....	17
6.	Instructions for checking the function of the system / quick start	18
7.	How to operate the 5V10.....	19
7.1.	Common introduction.....	19
7.2.	Technical data.....	19
7.3.	Initiation.....	19
7.4.	Service	20
7.5.	BNC Modulation input: MOD.....	20
7.6.	Actuator-socket: OUT	20
7.7.	Cable configuration of the external power supply.....	20
8.	Your notes.....	21



COMPETENCE
IN PRECISION

1. Introduction

This manual describes the voltage amplifier 5V10 from **piezosystem jena**. You will also find additional information regarding piezoelectric products.

Definition:

All systems from **piezosystem jena** such as electronics, actuators and optical systems are called units.

2. Certification of piezosystem jena

The company **piezosystem jena GmbH** has been certified by DIN EN ISO 9001 since 1999.





3. Declaration of conformity

EU-Declaration of conformity

This certificate is issued for the system:

PC board voltage amplifier 5V10

manufactured at:

piezosystem jena GmbH

Pruessingstrasse 27

07745 Jena / Germany

The system as described above herewith complies with the requirements of the European standards as follows:

EN 50082 (DIN VDE 0875 part 11) group 1, part 2

EN 55011, class B

declaration issued by:

piezosystem jena GmbH

head of the electronic department

Jena, Feb.15th, 2001



4. Instructions for using piezoelectrical elements and power supplies

- Piezoelectric actuators from **piezosystem jena** are controlled by voltages up to 150V. These values can be quite hazardous. Therefore read the installation instructions carefully and only authorized personal should handle the power supply.
- After transportation, piezoelectric actuators should be allowed to adapt for approximately 2 hours to the room temperature before being switched on
- Piezoelectric actuators are made from ceramic materials with and without metallic casings. The piezo-ceramic is a relatively brittle material. This should be noted when handling piezoelectrical actuators. All piezo-elements are sensitive to bending or shock forces.
- Due to the piezoelectric effect piezo-actuators can generate electrical charges by changing the mechanical load or the temperature or such actions described above
- Piezoelectric actuators are able to work under high compressive forces, only actuators with pre-load can be used under tensile loads (these tensile forces must be less then the pre-load, given in the data sheet)
- Please note that the acceleration of the ceramic material (e.g., caused by fall down, discharging or high dynamic application) will occur.
- After excitation of the actuators by a voltage in the upper control range, the ceramic will move and generate an opposite high voltage after disconnection.
- Heating of the ceramic material will occur during dynamic operation and is caused by structure conditional loss processes. This may cause failure if the temperature exceeds specified values cited below.
- With increasing temperature, up to the Curie temperature (usual values approx. 140°C - 250°C), the piezoelectric effect disappears.
- Piezoelectric actuators such stacks or various tables work electrically as a capacitance. These elements are able to store electrical energy over a long period (up to some days) and the stored energy may be dangerous.
- If the actuator remains connected to the drive electronics, it is unloaded within a second after shutdown and quickly reaches harmless voltage values.
- Piezo-actuators can generate voltages by warming or cooling only (caused by the longitudinal change). The discharge potential should not be ignored due to the inner capacitance. This effect is insignificant at usual room temperature.
- Piezo-actuators from **piezosystem jena** are adjusted and glued. Any opening of the unit will cause misalignment or possible malfunction and the guarantee will be lost.
- Please contact **piezosystem jena** or your local representative, if there are any problems with your actuator or power supply.



Caution!

Shock forces may damage the built-in ceramic element. Please avoid such forces, and handle the units with care, otherwise the guarantee will be lost.

5. Safety Instruction

- Do not open the units! There are no user serviceable parts inside and opening or removing covers may expose you to dangerous shock hazards or other risks. Refer all servicing to qualified service personnel.
- Allow adequate ventilation around the units so that heat can properly dissipate. Do not block ventilated openings or place the units near a radiator, oven or other heat sources. Do not put anything on top of the units except those that are designed for that purpose (e.g. actuators).
- Do not spill any liquids into the cabinet or use the units near water.
- Do not insert objects of any kind into the cabinet slots, as they may touch dangerous voltage points, which can be harmful or fatal or may cause electric shock, fire or equipment failure.
- Do not place any heavy objects on any cables (e.g. power cords, sensor cables, actuator cables, optical cables). Damage may cause malfunction or shock or fire!
- Do not place the units on a sloping or unstable cart, stand or table as they may fall or not work accurately.
- Work with the units only in a clean and dry environment! Only specially prepared units (e.g. actuators) can work under other conditions!
- Please use only original parts from **piezosystem jena**.
- **piezosystem jena** does not give any warranty for damages or malfunction caused by additional parts not supplied by **piezosystem jena**. Additional cables or connectors will change the calibration and other specified data. This can change the specified properties of the units and cause them to malfunction.
- Piezoelements are sensitive systems capable of the highest positioning accuracy. They will demonstrate their excellent properties only if they are handled correctly! Please mount them properly only at the special mounting points.

Immediately unplug your unit from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power supply cord or plug is damaged
- If liquid has been spilled or objects have fallen into the unit.
- If the unit has been exposed to rain or water.
- If the unit has been dropped or the housing is damaged.
- If the unit is not working properly.



COMPETENCE
IN PRECISION

6. Instructions for checking the function of the system / quick start

When you open the package, please check to make sure all the necessary parts are complete (see packing list) and nothing is damaged.

Check the electronics and the actuator for any visible damage:

- The top and bottom plate of the actuator (if it does not have another shape) should be parallel each to each other, without scratches.
- If there is any damage to the system please contact our local representative immediately!
- If the packaging material is damaged please confirm this with the shipping company.

Before you switch on the system, please check:

- The main voltage supplied in your country is the same as installed for the external power supply (not included in the shipment!).
- The secondary voltage (DC) matches with the amplifier (+5V).

Connect the power cable.

Connect the piezo-element by using the LEMO connector.

Offset is accomplished by the external offset (e.g. a load)

Because of the fast motion of the actuator a noise, crack can be heard. This is normal and not a malfunction.



7. How to operate the 5V10

7.1. Common introduction

The voltage amplifier 5V10 was especially developed for one channel positioning tasks in optics, laser physics, microbiology, machining. With an output noise less than 3mV it is well suited for positioning in the sub-nm range. It is well suited for OEM applications.

7.2. Technical data

Power supply:	+5V DC
no-load current [mA]	<100
Dimensions wxdxh [mm]:	80x55x20
Mass [g]:	200
Channels:	1
Power [W]:	1.5
Output current [mA]:	10
Output voltage (OUT):	1 ... +150V (adjustable by external modulation)
Output connector (OUT):	LEMO 0S.302
Inner resistance	10k Ω
Noise:	typical <0,3 mV _{RMS}

table 1: technical data 5V10

7.3. Initiation

Please connect the device with the wall outlet by using an external power supply. The actuators are driven by voltages up to +150V. Please pay attention to shock hazard protection.



COMPETENCE
IN PRECISION

7.4. Service

The actuator is connected to the power supply by a LEMO socket. The rest position of the actuator is adjusted, if the external triggering signal (range of 0...+5V) at the MOD input connector (BNC) = 0. To avoid damage to the actuators, it is recommended to adjust triggering signal in this way before switching on the amplifier. We recommend to switch on the amplifier approx. 2 hours before the measurement in the sub- μm range takes place to guarantee stable temperature circumstances. A constant temperature environment is necessary for precise positioning tasks. Please note, that a temperature change of $\Delta T = 5\text{K}$ will cause a $13\mu\text{m}$ increase in length of a 20cm steel rod. The special qualities of piezo-ceramics like hysteresis and creep can cause inaccuracies in the case of nonobservance. These basic qualities of piezo-elements are described in the "piezoline" tutorial in our catalog. Do not hesitate to contact our staff, if you need further information. By increasing the external triggering voltage the motion of the actuator will be done. The motion depends on the actuator specs, please refer the hysteresis data curve for details.

7.5. BNC Modulation input: MOD

The motion of the actuator may be remote controlled by using this input. The control signal must be in the range of 0 ... +5V. Switching signals are suitable as well as signals, generated by a function generator.

7.6. Actuator-socket: OUT

Please connect the piezo actuator by using this LEMO socket.

7.7. Cable configuration of the external power supply

Pin	Synonym	Description
White	PVR	+ Operating voltage +5V
Brown	GND	Ground
Green		Not used
Shield		Connected with the Ground

table 2: pin wiring of the external power supply

The equipment concept makes adaptations to customer preferences possible concerning the technical threshold values such as the main voltage or the output voltage. Please, contact our technical service department in order to discover the possibilities for your specific problem.


Adaptations are always to be paid by the customer.



8. Your notes



COMPETENCE
IN PRECISION





COMPETENCE
IN PRECISION